

- | | | |
|---------------|-----------------|-------------------------------|
| 1 – Coil | 5 – Core guider | 9 – Connector |
| 2 – Diaphragm | 6 – O-ring | 10 – Shell of manual control |
| 3 – Nut G1/8 | 7 – Flange | 11 – Screw for manual control |
| 4 – Spring | 8 – Body | 12 – Label |
| | | 13 – Washer 10,5 |
| | | 14 – Seal |


Guarantee and Service

The manufacturer is responsible for the solenoid valve properties during 12 months since delivery. In case of any claim it is required to present the solenoid valve, a document about buying (payment receipt) and this Installation, Service and Maintenance Instructions. The guarantee is not approved if the damages are caused by inappropriate impact to the solenoid valve or with not following these Instructions.

Under-and out-of –guarantee repairs can be performed by the manufactures.

Product liquidation

Components and pack can be used as source of secondary raw material.
Product is not source of environmental pollution and doesn't include danger scrap.



INSTALLATION, SERVICE AND MAINTENANCE INSTRUCTION

2-WAY SOLENOID VALVES PILOT OPERATED WITH INVERSE FUNCTION

Type: 2VE6IDA , 2VE10IDA
2VE12IDA, 2VE13IDA
2VE16IDA, 2VE25IDA
2VE32IDA, 2VE40IDA
2VE50IDA

REGADA

REGADA, s. r. o., Strojnícka 7
080 01 Prešov, Slovenská republika
Tel.: +421 51 7480 465, 7480 464
Fax: +421 51 7480 466

75 0351 03

